Dishwasher guide

Samsung DW60CG530B00ET · EN

14 place settings · 44 dB · Auto Open · third cutlery drawer. Model-specific reference for guests already familiar with dishwashers. It does not replace the manufacturer's complete safety instructions. Based on the German Casa Kelsa guide of 09 October 2026.

1. Appliance and controls

Three loading levels: top cutlery drawer, height-adjustable upper basket and lower basket with folding tines. Cutlery and small utensils go in the drawer; glasses, cups and bowls in the upper basket; plates, pots and pans in the lower basket. Adjust the upper basket to make room above or below, and fold tines where needed. The detergent/rinse-aid dispenser is on the door. The touch controls are hidden on the top edge of the door during operation.

POWER: on/off. Program: choose a cycle. Upper rack only / Lower rack only: wash only the selected basket. Sanitize: hygiene rinse, final rinse around 70 °C. Multi tab: combination tablets such as 3-in-1. Control Lock: lock controls. Delay Start: delay start by up to 24 hours. START: start. Hold START about 3 seconds: cancel and drain.

Typical sequence: open door > POWER > programme > options > START > close door.

2. Seven programmes

AUTO: easiest everyday choice for mixed dishes. The sensor detects soiling and adjusts the cycle.

ECO: normally soiled dishes; saves water/energy, around 3 hours 30 minutes. Suitable when time is less important, including overnight.

INTENSIVE: heavily soiled pots, pans and robust plates, including dried-on residues.

QUICK: lightly soiled dishes when time is short.

DELICATE: delicate glasses and lightly soiled delicate dishes.

EXPRESS 60: a short everyday programme for a normally soiled daily load, around one hour.

SELF CLEAN: clean the empty interior; run without dishes.

3. Options

Upper rack only: useful for a small load of glasses, cups and bowls. Lower rack only: useful for a small load of plates, pots or pans.

Sanitize raises the final rinse to about 70 °C. Not available with AUTO, QUICK, SELF CLEAN or DELICATE.

Multi tab is for combination tablets (3-in-1 etc.). Not available with AUTO, QUICK or SELF CLEAN.

Delay Start delays the start by up to 24 hours. Control Lock locks the controls; POWER remains usable.

4. Detergent, rinse aid and salt

Put detergent in the main-wash compartment on the door. For very heavy soiling, a small extra amount may be placed on the door for prewash.

Refill rinse aid when its indicator lights. Dosage can be adjusted from F1 to F5 in settings; factory setting F4.

Use dishwasher salt only. On the first fill, add water and then about 1 kg of salt.

5. Auto Open and drying

At the end of the programme, the door automatically opens about 10 cm to release steam and improve drying. Factory setting A1 enables Auto Open; it can be disabled in settings if needed. Keep the door edge and seal clean so that automatic opening is not obstructed.

6. Basic settings

Enter settings: switch on, then within 60 seconds hold AUTO for 5 seconds. The display shows 0:00.

Sound: Upper rack only > U0 = off / U1 = on. Use AUTO to toggle.

Auto Open: Multi tab > A0 = off / A1 = on. Factory setting A1.

Rinse-aid dosage: Delay Start > F1 to F5. Factory setting F4.

Water hardness: Self Clean > H1 to H6, from soft to hard. Factory setting H3.

Save: wait about 5 seconds after a change; it is saved automatically. These settings are useful after installation or a change in water supply, or for adjusting sound/Auto Open.

7. Care and periods without use

SELF CLEAN: run the empty machine if the interior or odour calls for cleaning. Samsung describes interior cleaning with water without aggressive cleaning agents.

Filter: remove periodically or if drainage is poor, wash under running water and refit correctly.

Spray arms: inspect jets and clean deposits or blocked openings. Keep the Auto Open door area and seal clean.

For a long absence, close the water tap and leave the interior dry. If freezing is possible, remove all water.

8. Error messages and cancellation

For a recurring fault or a water leak, switch off the appliance and contact Samsung service.

4C: water supply - check tap, inlet hose and filter. 5C: drainage - check filter and drain hose.

LC: leak detected - shut off water, disconnect power and contact service. AC: electronic communication error. HC: heating/excess temperature - contact service if repeated. tC: temperature sensor/thermistor. PC: distribution motor/water distribution.

To cancel and drain, hold START for about 3 seconds. The current cycle stops and the water is pumped out.

9. Technical information and source basis

14 place settings; 7 programmes; noise 44 dB(A); energy class D. ECO consumption: 10.5 litres of water per cycle / 85 kWh per 100 cycles. ECO duration around 3 hours 30 minutes.

Dimensions W × H × D: 598 × 815 × 550 mm. Rated power: 1,800 W; supply 220-240 V / 50 Hz. Aqua Stop: yes. Auto Open: yes. Wi-Fi / SmartThings is not listed as a function for this model.

Source basis of the German guide: Samsung Italia product/support pages for DW60CG530B00ET; Samsung DW6500AM user manual for controls, programmes, settings, care and error codes. Reference date: 09 October 2026. General dishwashing basics are outside this reference.